








No.	Component name	Qty
1	Mirror main part	1
2	Connection frame part	1
3	M4X5pan head screw with washer	1
4	battery box	1
5	M4X10screw	4

Installation of soft closing rotated mirror




④

Install the mirror frame to the cabinet




⑤

Pull out the connection frame, and punch the lower and stud in back side of mirror to the relevant hole in connection frame, and the punch in the upper end stud, and then hang over the mirror to the frame.




⑥

If install the frame at the left side of cabinet, then hang over the battery box to the hook mark "L", and connect the plug cord. If install the frame at the right side of cabinet, then hang over the battery box to the hook mark "R", and connect the plug cord. If it is the mirror without LED lighting, please ignore this step.



⑦

Fix M4X5 pan head screw with washer at this position



Notice:

1. Mirror without soft closing? Pull-out the mirror, and then pull out the damper by hand, and then close the mirror.
2. Soft closing not work well? Slide not smooth? Check whether the install hole right or not. Check whether it have some impurity such as sawdust in the inner of slide or not.
3. The mirror can't rotate, or the rotate not enough, or the soft closing not work well? Check the distance between the first hole and front edge of side panel not more than 182mm.