


Glasses Drawer



Cabinet Size:

450W


500W

600W

700W

800W






900W



10	Rail caps	1set
9	Glass Fixing Bracket	1pc
8	Cross Recessed Half-round Head Screws M4*8	2pcs
7	Cross Recessed Half-round Head Tapping Screws ST4.2*15	4pcs
6	Bottom Board (T: 12 ⁰ _{-0.5} mm)	1pc
No.	Components Name	Qty.

5	Side Glass Back/Front	2pcs
4	Curved Column	2sets
3	Cover Left/Right	2sets
2	Side Glass Left/Right	2pcs
1	Slide	1set
No.	Components Name	Qty.

Components Installation Instruction



Notes:

1. Runner doesn't steadily or pulse? ---Please ensure against wood chips or other scrap fall into runner interior during installation.
2. Runner doesn't work smoothly? ---Please check bottom and back panel measurement is up to the mustard or not; bottom pannel and cabinet is regularity or not; and runners are vertical and horizontal or not.
3. Runner can not clip on? ---Please ensue the runner is on the correct hole position.
4. Frame can not close well? ---Please ensue the runner is on the correct hole position.